





RZ147




RZ503 / RZ506 / RZ507



www.striebelundjohn.com


1 RZ147 / RZ503 / RZ506 / RZ507

Typ	A	B	C	D	E
RTW831	44	619	1194	1769	94
RTW841	44	619	1194	1769	144
RTW861	44	619	1194	1769	244
RTW1031	44	719	1394	2069	94
RTW1041	44	719	1394	2069	144
RTW1061	44	719	1394	2069	244




2 RZ147 / RZ503 / RZ506 / RZ507

Typ
RTW831
RTW841
RTW861
RTW1031
RTW1041
RTW1061




3 RZ147 / RZ503 / RZ506 / RZ507



4 RZ147 / RZ503 / RZ506 / RZ507

IP40



5 ! ➔ RZ503 / RZ506 / RZ507

IP54

